IMRD4500A LAYER 1 AND SIDE 1 COMPONENTS (VIEWED FROM SIDE 1)



IMRD4500A LAYER 4 AND SIDE 2 WITH TEST POINT LOCATIONS (VIEWED FROM SIDE 2)



COMPONENT OVERLAY DIAGRAMS